

DOUBLE DIAMOND SAFTIDOR FITTING INSTRUCTION

- A - Lockkeep
- B - Lockpost
- C - Channel
- D - S8 Castor bracket
- E - Lock protection plate
- F - S4 Butt hinge

1. Attach S4 Butt hinge to channel of sash.
2. Attach S71a Lockpost(B) using self-tapping screws onto channel(C) of sash through predrilled holes.
3. Fit S71a Lockkeep post(A) to wall.
4. Fit S8 Castor(D) into bottom of channel(C) and rivet in.
5. Fit sash complete with S4 Butt hinges and Lockpost to wall via use of Butt hinges.
6. Ensure Lockpost(A) and main sash are fitted to same height and castor fitted to allow sash to run across gap allowing lock hook to locate into Lockkeep without struggling to raise sash.
7. Attach S71c Lock Protection plate over Thumbturn lock with rivets/screws(E)

